

**Instruction:**


Step 1:  
Separate Fig①, ②, ③ & instruction part along the dotted line (total 4pcs);

Step 2:(holes for Lock Panel)  
(1) Draw a horizontal line on the door which is 1-m line distanced to the floor. (1-m line is only for reference, the position of this line can be adjusted according to the height of handle installed.);  
(2) Put Fig② against the door and align to door border; then align Line A-A to the line (1-m line) drawn in the 1st step;  
(3) Draw lines according to Fig②.

Step 3:(holes for Mortise)  
(1) Draw a center line according to door thickness;  
(2) Find scale number "0" in Fig①, align the "0" line to the center line drawn in the 1st step, and Line A-A to the 1-m line;  
(3) Making holes:  
a. Mark the size & position of the middle hole, make its depth as 116mm;  
b. Find 4 holes on each edge on template, put the template back to locate the grey area, and make its depth as 6.5 mm.

Step 4:(holes for Strike Plate)  
(1) After making holes on door, close the door and draw a horizontal 1-m line on door frame, then draw another center line according to thickness of door frame;  
(2) Align Line C-C on Fig③ to the center line on door frame, and align Line A-A on Fig③ to 1-m line on door frame;  
(3) Making holes:  
a. Mark the size & position of the middle hole, make its depth as 28mm;  
b. Find 6 holes on each edge on template, put the template back to locate the grey area, and make its depth as 3 mm.

Remarks:  
1. Position and size of the holes must be confirmed before cutting. 2. If there is shock absorption bar on door frame, its thickness should be excluded from door thickness.



**Instruction:**

Step 1:  
Separate Fig①, ②, ③ & instruction part along the dotted line (total 4pcs);

Step 2:(holes for Lock Panel)  
(1) Draw a horizontal line on the door which is 1-m line distanced to the floor. (1-m line is only for reference, the position of this line can be adjusted according to the height of handle installed.);  
(2) Put Fig② against the door and align to door border; then align Line A-A to the line (1-m line) drawn in the 1st step;  
(3) Draw lines according to Fig②.

Step 3:(holes for Mortise)  
(1) Draw a center line according to door thickness;  
(2) Find scale number "0" in Fig①, align the "0" line to the center line drawn in the 1st step, and Line A-A to the 1-m line;  
(3) Making holes:  
a. Mark the size & position of the middle hole, make its depth as 116mm;  
b. Find 4 holes on each edge on template, put the template back to locate the grey area, and make its depth as 6.5 mm.

Step 4:(holes for Strike Plate)  
(1) After making holes on door, close the door and draw a horizontal 1-m line on door frame, then draw another center line according to thickness of door frame;  
(2) Align Line C-C on Fig③ to the center line on door frame, and align Line A-A on Fig③ to 1-m line on door frame;  
(3) Making holes:  
a. Mark the size & position of the middle hole, make its depth as 28mm;  
b. Find 6 holes on each edge on template, put the template back to locate the grey area, and make its depth as 3 mm.

Remarks:  
1. Position and size of the holes must be confirmed before cutting. 2. If there is shock absorption bar on door frame, its thickness should be excluded from door thickness.